



## MODEL NO. 639 9MM AUTOMATIC PISTOL DOUBLE ACTION PARTS PRICE SCHEDULE

View #	Part Number	Part Description	View #	Part Number	Part Description
1	069590000	Barrel .....	45-51	063730000	Rear Sight Body Ass'y., Adjustable Sight Includes:
2	068010000	Barrel Bushing .....	45	068430000	Rear Sight Body .....
3-4	101390000	Disconnecter Assembly Includes:	46	068450000	Rear Sight Elevation Screw .....
3	069540000	Disconnecter (1) .....	47	071580000	Rear Sight Plunger .....
4	068040000	Disconnecter Pin .....	48	071590000	Rear Sight Plunger Spring .....
5	101360000	Drawbar .....	49	068470000	Rear Sight Slide .....
6	068060000	Drawbar Plunger .....	50	071870000	Rear Sight Windage Nut .....
7	068070000	Drawbar Plunger Spring .....	51	068480000	Rear Sight Windage Screw .....
8	068870000	Ejector Depressor Plunger .....	52	068400000	Rear Sight Base .....
9	068090000	Ejector Depressor Plunger Spring .....	53	100270000	Rear Sight Base Screw .....
10	103710000	Ejector Magazine Depressor .....	54	100780000	Rear Sight Body, Fixed Sight .....
11	068110000	Ejector Spring .....	55	068440000	Rear Sight Body Plunger .....
12	101270000	Extractor .....	56	063800000	Rear Sight Body Plunger Spring .....
13	100050000	Extractor Pin .....	57	063780000	Rear Sight Elevation Plunger .....
14	063310000	Extractor Spring .....	58	063810000	Rear Sight Elevation Spring .....
15	103660000	Firing Pin .....	59	100360000	Rear Sight Set Screw, Fixed Sight .....
16	100290000	Firing Pin Safety Lever .....	60	068500000	Recoil Spring .....
17	069250000	Firing Pin Safety Lever Plunger .....	61	100200000	Recoil Spring Guide Assembly Includes:
18	063890000	Firing Pin Safety Lever Spring .....	—	068510000	Recoil Spring Guide, N.I. (1) .....
19	100300000	Firing Pin Spring .....	—	100190000	Recoil Spring Guide Bushing, N.I. (1) .....
20-22	069290000	*Frame Assembly Includes:	—	068540000	Recoil Spring Guide Plunger, N.I. (1) .....
20	064660000	* Frame .....	—	068550000	Recoil Spring Guide Plunger Spring, N.I. (1) .....
21	068180000	Frame Stud .....	62	100920000	Sear .....
22	068670000	Slide Stop Button .....	63	068580000	Sear Pin .....
23-25	103050000	Hammer Assembly Includes:	64	103730000	Sear Release Lever .....
23	103040000	Hammer (1) .....	65	104230000	Sear Spring .....
24	068720000	Stirrup .....	66	068600000	Sear Spring Retaining Pin .....
25	068730000	Stirrup Pin .....	67	101070000	Sideplate .....
—	068210000	Hammer Pin, N.I. .....	68	100630000	Slide, Adjustable Sight .....
26	100570000	Insert .....	69	100650000	Slide, Fixed Sight .....
27	068230000	Insert Pin .....	—	100810000	Slide Assembly, Fixed Sight, N.I. .....
28-32	068240000	Magazine Assembly Includes:	70-73	064840000	Slide Stop Assembly Includes:
28	068250000	Magazine Butt Plate .....	70	066310000	Slide Stop (1) .....
29	068260000	Magazine Butt Plate Catch .....	—	068680000	Slide Stop Bar, N.I. .....
30	063210000	Magazine Follower .....	71	068690000	Slide Stop Plunger .....
31	068320000	Magazine Spring .....	72	068710000	Slide Stop Plunger Spring .....
32	068330000	Magazine Tube .....	73	064700000	Slide Stop Spiral Pin .....
33	064730000	Magazine Catch .....	74-75	161170000	Stock Ass'y., Black Ckrd. Nylon Includes:
34	068280000	Magazine Catch Nut .....	74	061330000	Stock left (1) .....
35	068290000	Magazine Catch Plunger .....	—	061320000	Stock, right (1) N.I. .....
36	068300000	Magazine Catch Plunger Spring .....	75	069190000	Stock Screw .....
37	103620000	Mainspring .....	76-79	103140000	Trigger Assembly Includes:
38	068350000	Mainspring Plunger .....	76	103150000	Trigger (1) .....
39	069600000	Manual Safety .....	77	068780000	Trigger Plunger .....
40	101030000	Manual Safety, Ambidextrous .....	78	068790000	Trigger Plunger Pin .....
41	100180000	Manual Safety Right Side Lever .....	79	061220000	Trigger Plunger Spring .....
42	100310000	Manual Safety Plunger .....	80	068230000	Trigger Pin .....
43	063720000	Manual Safety Plunger Spring .....	81	101260000	Trigger Play Spring .....
44	064910000	Manual Safety Screw .....	82	068770000	Trigger Play Spring Rivet .....

\* Requires factory installation.

Note (1): Sold as an assembly only.

N.I. = Not illustrated.

SPECIFY MODEL NUMBER, FINISH, PART NUMBER AND PART NAME WHEN ORDERING PARTS.